

PACK-A-TANK® Rainwater Storage

Installation Instructions:

1. Clear a level ground space equal to the empty dimensions of the tank with no sharp objects in contact with any part of the tank. (Optional Ground sheet is advised if any doubt about ground surface).
2. Roll-out Tank and orientate connections to predetermined positions.
3. Attach Inlet, Overflow and Outlet Connections to flexible tubes at least 600mm (24") long as shown in FIG 1. Flexibles should allow for 200-300mm of vertical and 100-150mm horizontal movement in the tank connections when filled and emptied.
4. A licenced Plumber should check that all the joints to existing stormwater pipes and pump are water tight and comply with local regulations.
5. Slight ground slopes of up to 1 degree (2 in 100) can be accommodated provided falls are toward the outlet.

